

Product Information

Wet-end



CORIPOL® GMT – Fatliquor for Pull-Up & Burnishing effect

Edition 2016

Features:

CORIPOL® GMT is based on natural and synthetic substances.

Light fastness:

Very good

Storage:

Store in a cool place.

Benefits:

CORIPOL® GMT is recommended for articles requiring a pull-up or burnishing effect.

CORIPOL® GMT imparts a “waxy handle”.

CORIPOL® GMT can be mixed with other fatliquors in the **CORIPOL®** range.

Application:

CORIPOL® GMT is a paste at temperatures lower than 35°C and is easily emulsifiable in water at 60°C. If used alone, it is recommended to prepare the emulsion just before adding it to the drum.

Shoe upper: 6-10% **CORIPOL® GMT** applied alone as the final drum treatment. It is used in a short float (50% approx.) at approx. 60°C.

On some leathers the application is improved by using 1-2% of **INVADERM® LU** added 10 minutes before the **CORIPOL® GMT**.

CORIPOL® GMT can be used in combination with other fatliquors in the range to obtain a good polish/burnished effect and a closed-grain.

Trade form at 20°C:

Light brown opaque viscous liquid

Solid content (%):

93.5 - 95.5

pH (10%):

6 – 8

This information is for guidance only.
A Product Specification is available on request.

Regarding toxicological and ecological data see the safety data sheet of above product.

CORIPOL® is a registered or filed trademark owned by or licensed to TFL in most countries.

Above data are based on the current state of knowledge. However, buyer is not released from his obligation to examine the material on receipt. Seller makes no warranty of merchantability or fitness for practical use or application