

Wet-End Shoe Upper

RECIPE NO.

ACI23555WE

CONTINUED

Process	%	kg	Product	Time
	200	10	water, 30°C	10'
Drain				
	100	5	water, 30°C	
	3	0,15	TANIGAN® MB-O LIQ	20'
	4	0,2	SELLATAN® MBS Powder	
	3	0,15	SELLATAN® PW	
RETANNING	4	0,2	TANIGAN® OS-IN	
	4	0,2	RETINGAN® RLF	60'
	100	5	water, 50°C	
	3	0,15	CORIPOL® DX-1202	
FATLIQUORING	3	0,15	CORIPOL® DX-3080	
	2	0,1	CORIPOL® SFC-I	
	2	0,1	BORRON® SAF	45'
	2	0,1	SELLATAN® MBS Powder	
	2	0,1	SELLATAN® PW	30'
FIXING	1	0,05	Formic acid	10'+20'
Drain				
	200	10	water, 30°C	10'
Drain				

Comments:

BORRON®, CORIPOL®, CROMENO®, DRYWALK®, INVADERM®, MAGNOPAL®, OROPON®, SELLA®, SELLASET®, SELLASOL®, SELLATAI by or licensed to TFL in most countries.

Our application recommendations are in line with our present state of knowledge. They do not, however, exempt the customer from supplied products for their intended purpose. Application of the products lies outside the scope of our control and therefore com We guarantee the satisfactory quality of our products subject to our general terms of sale and delivery.



Comments

Check for bath exhaustion

**cooling horse up overnight. Next day do
samm/sett/Hook to dry. then dry setting
to do grain shaving and buffing until .
required nap.**

N[®], and TANNESCO[®] are registered or filed trademarks, owned

n performing his own tests to determine the suitability of the
es within the customer's sphere of responsibility.